

JACKING & HOISTING

1995 Volvo 850

1995-96 WHEEL ALIGNMENT
Volvo - Jacking & Hoisting

940 (1995)
850, 960 (1995-96)


JACKING & HOISTING

FLOOR JACK OR HOIST

The following illustration indicates areas (parts) of underbody and frame used to raise and support vehicle with either floor jack or hoist. These points are indicated by shaded areas on frame. See Fig. 1.

EMERGENCY JACKING

Those points designated on body outline are designed for use with vehicle's jack and are indicated by circular dots. See Fig. 1. If floor jack or hoist is employed, extreme care should be exercised to avoid damaging outer body shell.



90H09546

Fig. 1: Jacking & Hoisting Points (Typical)