



## Relay Locations, 1987 240



- 2 Power junction box (12v from battery)
- 13 Headlight relay (stepped high/low beam)
- 104 Ignition Control Unit (ICU)
- 212 Fuse, LH fuel injection
- 214 ECU, LH fuel injection
- 217 Main relay, LH fuel injection, pump



- 12 Bulb failure warning relay
- 28 Turn signal flash relay
- 94 Fasten seat belt light
- 108 Transmission overdrive relay
- 124 Headlight relay
- 125 Fog light relay
- 126 Power window relay
- 129 Air conditioning relay
- 148 Windshield wiper interval relay
- 163 Tailgate wiper interval relay
- 167 Relay, delayed cabin light
- 171 Shift indicator control unit
- 175 Times relay, heated rear window
- 188 Central lock system relay (unlocking)
- 189 Central lock system relay (locking)